

Instructions for refilling Pre-Inked Stamps (PSI pre-inked stamp)

1. With the bottom cover off, push firmly on one of the two ends and slide out the little “drawer” that holds the stamp die box
2. Drip a few drops of Maxlight Ink (not too much!) into the slots on top. Carefully reinsert the die box back
3. Set the stamp aside for a couple of hours to give the ink time to distribute down throughout the cartridge.

Step 1



Step 2



Step 3 (Push the die box back)

